


MODEL BLP 17M

UNIT 1

ILLUSTRATED PARTS BREAKDOWN

From Serial Number : 034002482

Rev.B - Nov. 2014



MODEL BLP 17M

UNIT 2

PARTS LIST

N°	CODE	DESCRIPTION
1	4160.714	FRONT GRILLE
2	4162.919	COMBUSTION CHAMBER
3	4162.918	SHELL
4	4162.934	HANDLE
5	4162.910	THERMOSTAT
6	4162.909	THERMOSTAT COVER
7	4162.251	FAN
8	4160.044	MOTOR
9	4160.713	INLET GRILLE
10	4162.699	BURNER PLATE
11	4162.698	BURNER END
12	4162.697	BURNER PIPE
13	4160.707	ELECTRODE
14	4106.041	THERMOCOUPLE
15	4160.746	NOZZLE
16	4162.922	90° FITTING
17	4160.675	90° FITTING
18	4162.932	ELECTROVALVE
19	4160.653	GAS SAFETY VALVE
20	4160.048	CONNECTION
21	4161.854	CONNECTION BLOCK
22	4160.624	THREAD CAP
23	4162.914	LOWER BASE
24	4160.539	POWER CORD
25	4160.635	STRAIN RELIEF
26	4509.254	PIEZO IGNITOR
27	4160.637	SWITCH
28	4162.915	UPPER BASE

RECOMMENDED SPARE PARTS

N°	CODE	DESCRIPTION
5	4162.910	THERMOSTAT
6	4162.909	THERMOSTAT COVER
8	4160.044	MOTOR
13	4160.707	ELECTRODE
14	4106.041	THERMOCOUPLE
17	4162.932	ELECTROVALVE
18	4160.653	GAS SAFETY VALVE
25	4509.254	PIEZO IGNITOR


MODEL BLP 17M

UNIT 1

ILLUSTRATED PARTS BREAKDOWN

From Serial Number : 01033002160
Until Serial Number : 01033002160

Rev.A - May 2013



MODEL BLP 17M

UNIT 2

PARTS LIST

Pos.	Code N°	Description	Rev.A - May 2013
1	4160.714	OUTLET GRID	
2	4162.919	COMBUSTION CHAMBER	
3	4162.918	COVER	
4	4162.934	PLASTIC HANDLE	
5	4162.251	FAN Ø172 19°	
6	4160.044	ELECTRIC MOTOR	
7	4160.713	PLASTIC GRID	
8	4162.909	SAFETY THERMOSTAT COVER	
9	4162.910	SAFETY THERMOSTAT	
10	4160.707	IGNITOR ELECTRICAL FOLDER	
11	4162.697	BURNER PIPE	
12	4162.500	GROMMET	
13	4160.646	GROMMET	
14	4161.854	BLOCK FOR NOZZLE	
15	4160.746	GAS NOZZLE	
16	4160.048	GAS INLET NOZZLE	
17	4160.653	SAFETY GAS VALVE	
18	4160.562	ELECTROVALVE	
19	4160.675	GAS COCK	
20	4162.922	90° DEGREE ELBOW 1/8"	
21	4160.539	ELECTRIC CABLE	
22	4160.635	KEEPER WIRE DEVICE	
23	4162.914	LOWER PLASTIC BASE	
24	4162.597	PIEZO IGNITOR	
25	4160.637	SWITCH	
26	4160.646	GROMMET	
27	4160.639	RIVET POP	
28	4162.915	HIGHER PLASTIC BASE	
29	4162.699	PLATE BURNER	
30	4162.698	BURNER END	
31	4106.041	INTERRUPTED THERMOCOUPLE	
32	4106.043	THERMOCOUPLE NUT	

RECOMMENDED SPARE PARTS

Pos.	Code NR	Description	Rev.A - May 2013
6	4160.044	ELECTRIC MOTOR	
8	4162.909	SAFETY THERMOSTAT COVER	
9	4162.910	SAFETY THERMOSTAT	
10	4160.707	IGNITOR ELECTRICAL FOLDER	
17	4160.653	SAFETY GAS VALVE	
18	4160.562	ELECTROVALVE	
24	4162.597	PIEZO IGNITOR	
31	4106.041	INTERRUPTED THERMOCOUPLE	


MODEL BLP 17M

UNIT 1

ILLUSTRATED PARTS BREAKDOWN

From Serial Number:

Rev. Emiss. - May 2012



MODEL BLP 17M

UNIT 2

PARTS LIST

Pos.	Code NR	Description	Rev. Emiss. - May 2012
1	4160.714	OUTLET GRID	
2	4162.919	COMBUSTION CHAMBER	
3	4162.918	COVER	
4	4162.893	PLASTIC HANDLE	
5	4162.251	FAN Ø172 19°	
6	4160.044	ELECTRIC MOTOR	
7	4160.713	PLASTIC GRID	
8	4162.909	SAFETY THERMOSTAT COVER	
9	4162.910	SAFETY THERMOSTAT	
10	4160.707	IGNITOR ELECTRICAL FOLDER	
11	4162.697	BURNER PIPE	
12	4162.500	GROMMET	
13	4160.646	GROMMET	
14	4161.854	BLOCK FOR NOZZLE	
15	4160.746	GAS NOZZLE	
16	4160.048	GAS INLET NOZZLE	
17	4160.653	SAFETY GAS VALVE	
18	4160.562	ELECTROVALVE	
19	4160.675	GAS COCK	
20	4162.922	90° DEGREE ELBOW 1/8"	
21	4160.539	ELECTRIC CABLE	
22	4160.635	KEEPER WIRE DEVICE	
23	4162.914	LOWER PLASTIC BASE	
24	4162.597	PIEZO IGNITOR	
25	4160.637	SWITCH	
26	4160.646	GROMMET	
27	4160.639	RIVET POP	
28	4162.915	HIGHER PLASTIC BASE	
29	4162.699	PLATE BURNER	
30	4162.698	BURNER END	
31	4106.041	INTERRUPTED THERMOCOUPLE	
32	4106.043	THERMOCOUPLE NUT	

MODEL BLP 17M

UNIT 3

RECOMMENDED SPARE PARTS

Pos.	Code NR	Description	Rev. Emiss. - May 2012
6	4160.044	ELECTRIC MOTOR	
8	4162.909	SAFETY THERMOSTAT COVER	
9	4162.910	SAFETY THERMOSTAT	
10	4160.707	IGNITOR ELECTRICAL FOLDER	
17	4160.653	SAFETY GAS VALVE	
18	4160.562	ELECTROVALVE	
24	4162.597	PIEZO IGNITOR	
31	4106.041	INTERRUPTED THERMOCOUPLE	